



Foam Gasket Service Kit

Models: R3, Strive Compact



INSTALLATION INSTRUCTIONS:

Installation Time: 0.5 Hours

FOR SAFETY: Before installing kit, unplug power cord from wall outlet.

9006593 Kit Contents

Part No.	Description	Qty.
1054846	Gasket	2

1. Remove the two vacuum tool covers (Figure 1).
2. Thoroughly clean the top edge of each vacuum tool cover.
3. Carefully adhere the foam gasket along the top edge of the vacuum tool cover (Figure 2).
4. Press the gasket against a flat surface and roll the vacuum tool cover forward to bond the gasket (Figure 3).
5. Replace the vacuum tool covers.

