



# INSTRUCTION BULLETIN

No. 340813  
Machine: M20/T20  
Published: 11-2006  
Rev. 00

**NOTE: DO NOT DISCARD the Parts List from the Instruction Bulletin. Place the Parts List in the appropriate place in the machine manual for future reference. Retaining the Parts List will make it easier to reorder individual parts and will save the cost of ordering an entire kit.**

*NOTE: Numbers in parenthesis ( ) are reference numbers for parts listed in Bill of Materials.*

Installation instructions for **kit number 9001316**

## SYNOPSIS:

This kit contains the parts needed to install a fire extinguisher onto M20/T20 machines. Please follow step-by-step instructions.

## SPECIAL TOOLS / CONSIDERATIONS: NONE

(Estimated time to complete: 15 minutes)

## PREPARATION:

1. Park the machine on a clean level surface, turn off the machine, remove the key, and set the parking brake.

**FOR SAFETY: Before leaving or servicing machine, stop on level surface, turn off machine, and remove key.**

2. Open the engine shroud.

## INSTALLATION:

1. Mark two locations on the engine shroud to drill holes for the fire extinguisher bracket (1). Refer to Fig. 1 for dimensions.
2. Drill two 9/64" holes into the engine shroud. Use the fire extinguisher (1) bracket as a template for drilling the holes into the engine shroud. Refer to Fig. 1.





FIG. 1

3. Use two pan screws (2) to mount the fire extinguisher (1) bracket to the engine shroud. Refer to Fig. 2.
4. Secure the fire extinguisher (1) into the bracket. Refer to Fig. 2.



**FIG. 2**

**Bill of Materials for Extinguisher Kit, Fire, CI [M20 & T20]-9001316**

	<b>Tennant</b>	<b>Description</b>	<b>Qty.</b>
<b>Ref.</b>	<b>Part No.</b>		
▽	9001316	Extinguisher Kit, Fire, CI [M20 & T20]	1
▲	1 25312	Extinguisher, Fire, 1.5 Lb Dry	1
▲	2 382320	Screw, Pan, #12-16 X 0.50, F/Plastic	2
▲	3 1026898	Shroud, Eng, Extinguisher, Rwk	1

TENNANT COMPANY  
P. O. Box 1452  
Minneapolis, MN 55440-1452